

9950 Program Neutral K8A Motherboard RS232 Instruction List

Default baud rate: 115200 Version: 3.0.0 Time: 03/12/2021

INSTRUCTION	INDEX	REMARKS
6B303173413030300D	HDTV Power - STBY	
6B303173413030310D	HDTV Power - ON	
6B303173423030340D	Input HDMI	
6B303173423031340D	Input - HDMI1	
6B303173423032340D	Input - HDMI2	
6B303173423030360D	Input - VGA	
6B303173423030370D	Input - OPS1	
6B303173423030380D	Input - USB	
6B303173423030390D	Input - DP	
6B303173423030410D	Input - Android	
6B303173433x3x3x0D	Contrast	
6B303173443x3x3x0D	Brightness	
6B303173453x3x3x0D	Sharpness	
6B303173463x3x3x0D	Saturation	
6B303173473x3x3x0D	Hue	
6B303173483030300D	Color Mode - NORMAL	
6B303173483030310D	Color Mode - WARM	
6B303173483030320D	Color Mode - COLD	
6B303173483030330D	Color Mode - USER	
6B3031734A3x3x3x0D	Bass	
6B3031734B3x3x3x0D	Treble	
6B3031734C3x3x3x0D	Balance	
6B3031734E3030300D	OSD Language - English	
6B3031734E3030310D	OSD Language - French	
6B3031734E3030320D	OSD Language - Spanish	
6B3031734E3030330D	OSD Language - Traditional Chinese	
6B3031734E3030340D	OSD Language - Simple Chinese	
6B3031734F3030300D	Power Lock - Unlock	
6B3031734F3030310D	Power Lock - Lock	

1-833-TOUCHVW (868-2489)

TouchView Interactive, 830 W Chestnut St., Brockton, MA 02301



9950 Program Neutral K8A Motherboard RS232 Instruction List

Default baud rate: 115200 Version: 3.0.0 Time: 03/12/2021

6B303173503x3x3x0D	Volume	
6B303173503230300D	Volume - Down	
6B303173503230310D	Volume - Up	
6B303173513030300D	Mute - OFF	
6B303173513030310D	Mute - ON	
6B303173523030300D	Button Lock - Unlock	
6B303173523030310D	Button Lock - Lock	
6B303173533030300D	Menu Lock - Unlock	
6B303173533030310D	Menu Lock - Lock	
6B303173543x3x3x0D	Number	
6B303173553030300D	Key Pad - UP	
6B303173553030310D	Key Pad - DOWN	
6B303173553030320D	Key Pad - LEFT	
6B303173553030330D	Key Pad - RIGHT	
6B303173553030340D	Key Pad - ENTER	
6B303173553030350D	Key Pad - INPUT	
6B303173553030360D	Key Pad - MENU	
6B303173553030370D	Key Pad - EXIT	
6B303173563030300D	Remote Control - DISABLE	
6B303173563030310D	Remote Control - ENABLE	
6B3031735859xxxx0D	Date - Year	
6B303173584Dxxxx0D	Date - Month	
6B3031735844xxxx0D	Date - Day	
6B3031735948xxxx0D	Date - Hour	
6B303173594Dxxxx0D	Date - Min	
6B3031735953xxxx0D	Date - Sec	



1-833-TOUCHVW (868-2489)

TouchView Interactive, 830 W Chestnut St., Brockton, MA 02301

9950 Program Neutral K8A Motherboard RS232 Instruction List

Default baud rate: 115200 Version: 3.0.0 Time: 03/12/2021

6B3031735A3030300D	Restore Default	
6B303167613030300D	Get Constrast	
6B303167623030300D	Get Brightness	
6B303167633030300D	Get Sharpness	
6B303167643030300D	Get Saturation	
6B303167653030300D	Get Hue	
6B303167663030300D	Get Volume	
6B303167673030300D	Get Mute	
6B303167683030300D	Get Input Source	
6B303167693030300D	Get Power Status	
6B3031676A3030300D	Get Remote Control	
6B3031676B3030300D	Get Power Lock	
6B3031676C3030300D	Get Button Lock	IR Key Pad
6B3031676D3030300D	Get Menu Lock	Menu - Android
6B3031676E3030300D	Get Temperature	
6B3031676F3030300D	Get Operation Time	Get Boot Time Amount - Runtime
6B303167704D30300D	Get Date - Month	
6B303167704430300D	Get Date - Day	
6B303167714830300D	Get Date - Hour	
6B303167714D30300D	Get Date - Min	
6B303167715330300D	Get Date - Sec	
6B303167723030300D	Get Device Name	
6B303167733030300D	Get MAC Address	

1-833-TOUCHVW (868-2489)

TouchView Interactive, 830 W Chestnut St., Brockton, MA 02301



9950 Program Neutral K8A Motherboard RS232 Instruction List

Return Value Format

Return Contrast = 6B303172613x3x3x0D	
Return Brightness = 6B303172623x3x3x0D	
Return Sharpness = 6B303172633x3x3x0D	
Return Saturation = 6B303172643x3x3x0D	
Return Hue = 6B303172653x3x3x0D	
Return Volume = 6B303172663x3x3x0D	
Return Mute On = 6B303172673030310D	
Return Mute Off = 6B303172673030300D	
Return Input Source = 6B 30 31 72 68 3x 3x 3x 0D	

Return Input HDMI No Signal = 6B303172683030340D	
Return Input HDMI1 No Signal = 6B303172683031340D	
Return Input HDMI2 No Signal = 6B303172683032340D	
Return Input VGA No Signal = 6B303172683030360D	
Return Input OPS1 No Signal = 6B303172683030370D	
Return Input USB No Signal = 6B303172683030380D	
Return Input DP No Signal = 6B303172683030390D	
Return Input Android No Signal = 6B303172683030410D	
Return Input HDMI Signal = 6B303172683130340D	
Return Input HDMI1 Signal = 6B303172683131340D	
Return Input HDMI2 Signal = 6B303172683132340D	
Return Input VGA Signal = 6B303172683130360D	
Return Input OPS1 Signal = 6B303172683130370D	
Return Input USB Signal = 6B303172683130380D	
Return Input DP Signal = 6B303172683130390D	
Return Input Android Signal = 6B303172683130410D	

1-833-TOUCHVW (868-2489)

TouchView Interactive, 830 W Chestnut St., Brockton, MA 02301



9950 Program Neutral K8A Motherboard RS232 Instruction List

Return Value Format

Return Power Status = 6B303172693030310D	Here is the String - Now On
Return Remote Control On = 6B3031726A3030310D	
Return Remote Control Off = 6B3031726A3030300D	
Return Power Lock = 6B3031726B3030310D	
Return Power Unlock = 6B3031726B3030300D	
Return Button Lock = 6B3031726C3030310D	
Return Button Unlock = 6B3031726C3030300D	
Return Menu Lock = 6B3031726D3030310D	
Return Menu Unlock = 6B3031726D3030300D	
Return Temperature = 6B3031726E3x3x3x0D	
Return Operation Time = 6B30316F3x3x3x3x0D	
Return Date Month = 6B303172704Dxxxx0D	
Return Date Day = 6B3031727044xxxx0D	
Return Date Hour = 6B3031727148xxxx0D	
Return Date Min = 6B303172714Dxxxx0D	
Return Date Sec = 6B3031727153xxxx0D	
Return Device Name = 6B3031723xxxxxxxx0D	
Return MAC Address = 6B303172733xxxxxxxx0D	

1-833-TOUCHVW (868-2489)

TouchView Interactive, 830 W Chestnut St., Brockton, MA 02301

